


Montageanleitung / Mounting Instruction

SPRINT Metall-Produktprogramm / SPRINT Metal-products



EMSKE ** EMV-Z / ESSKE(-4) ** EMV-Z



Kabelverschraubung / cable gland	M [Nm] ¹⁾	D [mm]
E*SKE(-4) 12 EMV-Z [+ E*MU-EMV 12]	4,0	4 - 7
E*SKE(-4) 16 EMV-Z [+ E*MU-EMV 16]	4,0	5 - 10
E*SKE(-4) 20 EMV-Z [+ E*MU-EMV 20]	8,0	6 - 13
E*SKE(-4) 25 EMV-Z [+ E*MU-EMV 25]	10,0	10 - 17
E*SKE(-4) 32 EMV-Z [+ E*MU-EMV 32]	20,0	13 - 21
E*SKE(-4) 40 EMV-Z [+ E*MU-EMV 40]	20,0	16 - 28
E*SKE(-4) 50 EMV-Z [+ E*MU-EMV 50]	30,0	21 - 35
E*SKE(-4) 63 EMV-Z [+ E*MU-EMV 63]	40,0	34 - 48
E*SKE(-4) 75 EMV-Z [+ E*MU-EMV 75]	50,0	48 - 62



WISKA Hoppmann GmbH • Kisdorfer Weg 28 • 24568 Kaltenkirchen • Germany

1) Die angegebenen Drehmomente wurden unter Laborbedingungen und mit Prüfdomen nach EN 62444 ermittelt. Damit handelt es sich bei den Drehmomenten um Richtwerte. Die Drehmomente sollten unter Normal Klima für Stutzen und Gegenmutter eingehalten werden. Je nach verwendeten Kabel ist beim Anziehen der Hutmutter darauf zu achten, dass die Drehmomente nicht überschritten werden um Kabelbeschädigungen zu vermeiden.

The specified torques were determined under laboratory conditions and with test mandrels according to EN 62444. The torques are therefore guide values. The torques should be observed under normal climatic conditions for fittings and locknuts. Depending on the cable used, care must be taken when tightening the cap nuts that the torques are not exceeded in order to avoid cable damage.

(Technische Änderungen vorbehalten. / Technical changes reserved.)

Moln_SPRINT Metall EX_2022-01-26