




Montageanleitung / Mounting Instruction

SPRINT Metall-Produktprogramm / SPRINT Metal-products



EMSKV ** / EMSKVS ** / EMSKVZ ** / ESSKV(-4) **



Kabelverschraubung / cable gland	M [Nm] ¹⁾	M _s [Nm] ¹⁾	D [mm]
E*SKV 12 / E*SKVS 12 [+ E*MU 12]	4,0	-	3 - 7
E*SKV 16 / E*SKVS 16 / E*SKVZ 16 [+ E*MU 16]	4,0	0,3	4,5 - 10
E*SKV 20 / E*SKVS 20 / E*SKVZ 20 [+ E*MU 20]	8,0	0,4	6 - 13
E*SKV 25 / E*SKVS 25 / E*SKVZ 25 [+ E*MU 25]	10,0	0,4	9 - 17
E*SKV 32 / E*SKVS 32 / E*SKVZ 32 [+ E*MU 32]	20,0	0,5	13 - 21
E*SKV 40 / E*SKVS 40 / E*SKVZ 40 [+ E*MU 40]	20,0	0,5	16 - 28
E*SKV 50 / E*SKVS 50 / E*SKVZ 50 [+ E*MU 50]	30,0	0,6	21 - 35
E*SKV 63 / E*SKVS 63 / E*SKVZ 63 [+ E*MU 63]	40,0	0,6	34 - 48



WISKA Hoppmann GmbH • Kisdorfer Weg 28 • 24568 Kaltenkirchen • Germany

1) Die angegebenen Drehmomente wurden unter Laborbedingungen und mit Prüfdomen nach EN 62444 ermittelt. Damit handelt es sich bei den Drehmomenten um Richtwerte. Die Drehmomente sollten unter Normalklima für Stutzen und Gegenmuttern eingehalten werden. Je nach verwendeten Kabel ist beim Anziehen der Hutmuttern darauf zu achten, dass die Drehmomente nicht überschritten werden um Kabelbeschädigungen zu vermeiden.

The specified torques were determined under laboratory conditions and with test mandrels according to EN 62444. The torques are therefore guide values. The torques should be observed under normal climatic conditions for fittings and locknuts. Depending on the cable used, care must be taken when tightening the cap nuts that the torques are not exceeded in order to avoid cable damage.

(Technische Änderungen vorbehalten. / Technical changes reserved.)

Moln_SPRINT Metall_2022-01-06