

Installation of B or C Lashed Cable Supports When Used With Panduit Stackable Cable Spacers

Stackable Spacers

The stackable spacer is designed and constructed so that it can be snapped into another spacer by hand. Adding a spacer increases the height of the assembly by 1/2 inch (12.7mm). Spacers provide two different size grooves to accommodate a variety of cable diameters. Stackable spacers are designed to be used with Dura-Ty Cable Ties or Pan-Steel Metal Locking Ties.

On Cables Larger than 1.0" Diameter

Determine the required spacing and assemble the necessary spacers. Position the spacer(s) between the messenger strand and the cable so the longer length of the spacer is perpendicular to the cable and the strand, as shown in figure A. Next, thread the tip of the Dura-Ty Cable Tie or Pan-Steel Metal Locking Tie through the slot provided in the side of the spacer(s) so the head of the cable tie is on the top, adjacent to the strand. Finish the installation by threading the tip of the cable tie through the head by hand and tension with the appropriate installation tool.




Figure A




Figure B

Spacing Two Cables Apart

Position spacer as shown in figure C and use either a B or C lashed cable support, as outlined, for attaching a cable to a strand. Can be used for either aerial or underground applications.



Figure C

Installation of B or C Lashed Cable Supports When Used With Panduit Stackable Cable Spacers

Stackable Spacers

The stackable spacer is designed and constructed so that it can be snapped into another spacer by hand. Adding a spacer increases the height of the assembly by 1/2 inch (12.7mm). Spacers provide two different size grooves to accommodate a variety of cable diameters. Stackable spacers are designed to be used with Dura-Ty Cable Ties or Pan-Steel Metal Locking Ties.

On Cables Larger than 1.0" Diameter

Determine the required spacing and assemble the necessary spacers. Position the spacer(s) between the messenger strand and the cable so the longer length of the spacer is perpendicular to the cable and the strand, as shown in figure A. Next, thread the tip of the Dura-Ty Cable Tie or Pan-Steel Metal Locking Tie through the slot provided in the side of the spacer(s) so the head of the cable tie is on the top, adjacent to the strand. Finish the installation by threading the tip of the cable tie through the head by hand and tension with the appropriate installation tool.




Figure A




Figure B

Spacing Two Cables Apart

Position spacer as shown in figure C and use either a B or C lashed cable support, as outlined, for attaching a cable to a strand. Can be used for either aerial or underground applications.




Figure C